

MANUAL FILLING INSTRUCTIONS



"manual filling head"

picture A

- 1) Before using, clean and sanitize all the parts of the "manual filling head" (picture A),



picture B

- 2) Make sure valves ② and ③ are closed,
- 3) Before filling each keg, spray a little alcohol based sanitization fluid onto the spear of the Polykeg® and filling head,
- 4) Connect the "manual filling head" to the Polykeg®,
- 5) Check pressure on the gauge ④,
- 6) Carefully open valve ② (*product*),
- 7) Carefully open valve ③ (*vent*) to regulate the pressure and control the speed of filling,
- 8) When you reach the correct level of filling, close valve ③ and valve ②,
(If required you can adjust the pressure inside the Polykeg® using valves ② and ③),
- 9) Remove the "manual filling head".
(Before lifting handle ① make sure handle ② and ③ are completely closed).